



FILTER CLEANING PROCEDURES

Your filters should be cleaned as required to maintain water clarity and as preventative maintenance for your spa. The frequency and duration of use, and the number of occupants, all contribute to determining the appropriate time between filter cleanings. The more frequent the use, the more frequent filter cleanings are required.

REGARDLESS OF HOW OFTEN OR HOW INFREQUENTLY YOUR SPA IS USED, YOUR FILTER(S) NEED TO BE CLEANED A MINIMUM OF ONCE A MONTH!!!!

With each *MONTHLY* cleaning, rotate the position of each filter in the filter compartment. Replace your filters with NEW filters every 2-3 years.

- Once a month, using a hose, rinse your filter(s) with a hard spray of water up and down each pleat. Rotate the filter while spraying to remove any debris lodged between the filter pleats.
- To help maintain clear water, it is recommended that you clean your filters using Filter Cleaner and Degreaser to remove mineral and oil buildup every time you drain or refill your spa.
 - If using Filter Cleaner, soak the filter in the degreaser according to the package directions, then place the filter on a clean surface and spray until clean using a garden hose.
 - If using an Instant Filter Cleaner, saturate the filter with water and spray cleaner over total surface area for maximum effect. Wait 3 -6 minutes then rinse filter thoroughly with hose. Rotate your filter(s) while spraying to remove any debris lodged between the filter pleats.

WARNING: Do not use the spa with the filter cartridges, or standpipe(s) removed!